


TOUR

50432 SILVER




LIT Pritvirtinimo instrukcijos
PL Instrukcja montażu
CZ Návod na montáž
SK Návod na montáž
SLO Navodila za pritrjevanje
HR Uputa za sastavljanje
HU A felszerelés módja
GR Οδηγίες συναρμολόγησης
UA Інструкція з монтажу
BY Інструкцыя па мантажы
RO Instrucțiuni de montare
TK Uydurma talimat
N Monteringsveiledning



I Istruzioni per il montaggio
GB Fitting instructions
F Instructions de montage
D Montageanleitung
E Instrucciones de montaje
NL Montage-instructies
DK Montering instruktion
FIN Asennusohje
S Monteringsanvisning
RU Инструкция по установке
PT Instruções de Montagem
EST Paigaldusjuhend
LAT Stiprināšanas instrukcija




50561




50561




50562





50562






50562




50562




a = b ✓ OK






GLASS, CHROME




NO




50563

OK


OPTION I






OPTION II




OPTION III









✓OK



NO X



NO X






✓OK


TOUR

kg 3,50 kg

max 30 kg




ACCESSORIES




50138




50563




50534



50535



40070



50591



50532



WWW.AGURI.EU