



50485

ACTIVE E-BIKE



AGURI

WWW.AGURI.EU



LIT Pritvirtinimo instrukcijos

PL Instrukcja montażu

CZ Návod na montáž

SK Návod na montáž

SLO Navodila za pritrjevanje

HR Uputa za sastavljanje

HU A felszerelés módja

GR Οδηγίες συναρμολόγησης

UA Інструкція з монтажу

BY Інструкцыя па мантажы

RO Instrucțiuni de montare

TK Uydurma talimat

N Monteringsveiledning

I Istruzioni per il montaggio

GB Fitting instructions

F Instructions de montage

D Montageanleitung

E Instrucciones de montaje

NL Montage-instructies

DK Montering instruktion

FIN Asennusohje



S Monteringsanvisning














RU Инструкция по установке

PT Instruções de Montagem

EST Paigaldusjuhend


LAT Stiprināšanas instrukcija






	50485	
 KG		
	19,5 KG	
50 KG	-19,5 KG	30,5 KG
60 KG	-19,5 KG	40,5 KG
70 KG	-19,5 KG	50,5 KG
80 KG	-19,5 KG	60,5 KG


1.




2.




3.




4.




5.




6.




7.





8.






13 PIN




FOR LOAD






CLOSE

PULL UP




OPEN


PUSH





OK



NO!




OK












NO


OK




min 20 mm
max 80 mm







CHECK



LIFT AND TOW


ACCESSORIES




50532



50484
LOADING RAMP




40070



13 PIN / 7 PIN

50072



50538

30 x 30 cm