


GIZA 2

50408

GIZA 3

50410




LIT Pritvirtinimo instrukcijos
PL Instrukcja montażu
CZ Návod na montáž
SK Návod na montáž
SLO Navodila za pritrjevanje
HR Uputa za sastavljanje
HU A felszerelés módja
GR Οδηγίες συναρμολόγησης
UA Інструкція з монтажу
BY Інструкцыя па мантажы
RO Instrucțiuni de montare
TK Uydurma talimat
N Monteringsveiledning



I Istruzioni per il montaggio
GB Fitting instructions
F Instructions de montage
D Montageanleitung
E Instrucciones de montaje
NL Montage-instructies
DK Montering instruktion
FIN Asennusohje
S Monteringsanvisning
RU Инструкция по установке
PT Instruções de Montagem
EST Paigaldusjuhend
LAT Stiprināšanas instrukcija





50561



50561




50562





50562




50562




50562




a = b ✓ OK






GLASS, CHROME




NO



50563

OK


OPTION I






OPTION II




OPTION III









✓OK



NO X



NO X



✓OK

GIZA 2


kg 5,60 kg

 + **max 30 kg**

GIZA 3

kg 5,90 kg


 + **max 45 kg**



20 km --> CHECK




ACCESSORIES




50138




50563




50534



50535



40070



50591



50532



WWW.AGURI.EU